

i-TPMS



User Manual





*Note: Pictures illustrated here are for reference purpose only. Due to continuing improvements, actual product may differ slightly from the product described herein and this User Manual is subject to change without notice.

Safety Precautions

Read all safety warnings and instructions. Failure to heed these warnings and instructions may result in electric shock, fire and/or serious injury.
Save all safety warnings and instructions for future reference.


- There are no user serviceable parts. Have the device serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the device is maintained. Disassembling the device will void the warranty right.
- CAUTION: This device contains an internal Lithium Polymer battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns, do not disassemble, crush, pierce or dispose of the battery in fire or water.
- This product is not a toy. Do not allow children to play with or near this item.
- Do not expose the device to rain or wet conditions.
- Do not place the device on any unstable surface.
- Never leave the device unattended during charging process. The device must be placed on a non-flammable surface during charging.
- Handle the device with care. If the device is dropped, check for breakage and any other conditions that my affect its operation.
- Put blocks in front of the drive wheels and never leave the vehicle unattended while testing.
- Do not operate the tool in explosive atmospheres, such as in the presence of flammable liquids, gases, or heavy dust.
- Keep the device dry, clean, free from oil, water or grease. Use a mild detergent on a clean cloth to clean the outside of the device when necessary.
- People with pacemakers should consult their physician(s) before use. Electromagnetic fields in close proximity to heart pacemaker could cause pacemaker interference or pacemaker failure.

Safety Precautions

- Use the device only with the specific diagnostic tool that comes loaded with the TPMS module and the Android smartphone that is installed with i-TPMS app.
- Do not install programmed TPMS sensors in damaged wheels.
- While programming a sensor, do not place the device close to several sensors at the same time, which may result in programming failure.
- The warnings, precautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Components & Controls

i-TPMS is a professional TPMS (Tire Pressure Monitoring System) service tool. It can work with the specific diagnostic tool or smartphone (needs to be loaded with i-TPMS app) to perform various TPMS functions.



1. Charging LED
Red means Charging; Green means Fully Charged.

2. UP Button

3. DOWN Button

4. Charging Port

5. Sensor Slot
Insert the sensor into this slot to activate and program it.

6. Display Screen

7. POWER Button
Turn on/off the tool.


8. OK (Confirm) Button

Technical Parameters


Screen: 1.77 inch
Input voltage: DC 5V
Size: 205*57*25.5mm
Working Temperature: 0°C~45°C
Storage Temperature: -20°C~70°C

Accessory Included

While opening the package for the first time, please carefully check the following components. Common accessories are same, but for different destinations, the accessories may vary. Please consult from the seller.



i-TPMS Device



Charging Cable

(For charging the i-TPMS device.)



User Manual

Working Principle


Below illustrates how the i-TPMS works with the specific diagnostic tool and smarthone.

Diagnostic Tool*
(Using **TPMS** module)

or

Smart Phone*
(Using **i-TPMS** App)






i-TPMS

*** Notes:**

- The diagnostic tool must be specific scanner loaded with the TPMS module.
- Due to hardware limitation, The i-TPMS app on the smartphone achieves less functions than the TPMS module on the specific diagnostic tool.
- A stable wireless communication should be established between the i-TPMS and diagnostic tool or smartphone.

RF(Radio Frequency) Communication*



Vehicle

Initial Use

1. Charging & Powering On

Plug one end of the charging cable into the charging port of the i-TPMS, and the other end to an external power adaptor (not included), then connect the power adaptor to the AC outlet. While being charged, the LED illuminates red. Once the LED changes into green, it indicates the charging is complete.

Press the POWER button to turn it on. A beep will sound and the screen will light up.

2. Button Operations

▲/▼	Switches to different tire positions.

⏻	Press it for about 3 seconds to turn it on/off.
	• Screen On: Press it once to enter hibernate mode.
	  • If the device is not charged and there is no operation made for 30 minutes, it will automatically power off.
	  • If the device is charging and there is no operation made for 5 minutes, it will automatically enter hibernate mode to conserve battery power.
	• Screen Off (hibernate): Press it once to wake it up.


OK	Press it to confirm the current operation.

3. i-TPMS App Download (Only for Android Smartphone users)

For Android system smartphone user, scan the following QR code or the QR code on the back of the i-TPMS device to download and install the i-TPMS app on the phone.

Getting Started

For initial use, please follow the flow chart below to start using it.




*Notes:

1. When scanning available i-TPMS device, make sure it has been powered on. After searching, tap it to pair up via Bluetooth. If the firmware version of the i-TPMS is too low, the system will automatically upgrade it.
2. For indirect TPMS vehicle, only the Learning function is supported. For vehicle using Direct TPMS, it generally includes: Activation, Programming, Learning and Diagnosis. The available TPMS functions may vary for different vehicles being serviced and TPMS apps being used.

Job Menu

This section only applies to the Android smartphone user using the i-TPMS app.

Open the i-TPMS app, the following screen will appear:



A. Settings button

Tap to enter the settings screen.

B. Bluetooth pairing button

Tap to scan for available bluetooth devices and pair it up. After paired, an link icon will appear on the screen.

C. Function module

Select Vehicle - Tap to select the desired vehicle manufacturer.

Firmware Update - Update the firmware version of specific TPMS activation & programming tools.

OE Query - Tap to check the OE number of the sensors.


Repair Information - Tap to check repair guides, cases and skills, etc.

History Report - Tap to view the historical reports TPMS test report.

Choose Car Model Area - Tap to select an area to quickly find the car model.

TPMS Operations

Here we take diagnostic tool for example to demonstrate how to perform TPMS operations since the TPMS module of diagnostic tool covers all TPMS functions on the i-TPMS app on the smartphone.




1. Activate Sensor

This function allows users to activate TPMS sensor to view sensor data such as sensor ID, tire pressure, tire frequency, tire temperature and battery condition.

*Note: The tool will do TPMS test in a sequence of FL (Front Left), FR (Front Right), RR (Rear Right), LR (Rear Left) and SPARE, if the vehicle has the option for the spare. Or, you can use the ▲/▼ button to move to the desired wheel for testing.

For universal sensors, place the i-TPMS alongside the valve stem, point toward the sensor location, and press the **OK** button. Once the sensor is successfully activated and decoded, i-TPMS will vibrate slightly and the screen will display the sensor data.



*Notes:


- For early magnet-activated sensors, place the magnet over the stem and then place the i-TPMS alongside the valve stem.
- If the TPMS sensor requires tire deflation (of the order of 10PSI), then deflate the tire and place the i-TPMS alongside the stem while pressing the OK button.

2. Program Sensor

This function allows users to program the sensor data to the specific brand sensor and replace faulty sensor with low battery life or one that is not functioning.

There are four options available for programming the sensor: Auto Create, Manual Create, Copy by Activation and Copy by OBD.


*Note: Do not place the device close to several sensors at the same time, which may result in programming failure.



Method 1- Auto Create

This function is designed to program the specific brand sensor by applying random IDs created according to the test vehicle when it is unable to obtain the original sensor ID.

1. Select the wheel which needs to be programmed on the screen, insert a sensor into the sensor slot of the i-TPMS, and tap **Auto** to create a new random sensor ID.



2. Tap **Program** to write in the new created sensor ID to the sensor.

*Note: If Auto is selected, the TPMS Relearn operation needs to be performed after programming all required sensor.

Method 2 - Manual Create

This function allows users to manually enter sensor ID. Users can enter the random ID or the original sensor ID, if it is available.

TPMS Operations

1. Select the wheel to be programmed on the screen, insert a sensor into the sensor slot of the i-TPMS, and tap **Manual**.
2. Use the on-screen virtual keypad to input a random or original (if available) sensor ID and tap **OK**.
   *Note: Do not enter the same ID for each sensor.
3. Follow the on-screen prompts to write in the sensor ID to the sensor.

*Notes:

- If a random ID is entered, please perform the TPMS Relearn function after programming is finished. If the original ID is entered, there is no need to perform Relearn function.
- If a vehicle does not support Learn function, please select **Manual** to enter the original sensor ID manually, or trigger the original sensor at the activation screen to get its information, before programming the sensor.

Method 3 - Copy By Activation

This function allows users to write in the retrieved original sensor data to the specific brand sensor. It is used after the original sensor is triggered.

1. From the activation screen, select the specific wheel position and trigger the original sensor. After the information is retrieved, it will be displayed on the screen.
2. Insert a sensor into the sensor slot of the i-TPMS, and tap **Copy by activation**.
3. Tap **Program** to write in the copied sensor data to the sensor.

*Note: Once programmed with **Copy**, the sensor can be installed in the wheel directly to be mounted on the vehicle and the TPMS warning light will turn off.

Method 4 - Copy By OBD

This function allows users to write in the saved sensor information to the LAUNCH sensor after performing Read ECU ID. This function requires a connection with the vehicle's DLC port.

TPMS Operations

1. Connect the tool to the vehicle's DLC port, tap **Read ECU ID** to start reading the sensor Ids and positions for viewing.
2. Insert a new sensor into the sensor slot of the i-TPMS, select the desired wheel position and tap **Copy by OBD**.
3. Tap **Program** to write in the copied sensor data to the sensor.

3. Relearning (Only available on diagnostic tool)

This function is used to write the newly programmed sensor IDs into the vehicle's ECU for sensor recognition.

Relearn operation applies only when the newly programmed sensor IDs are different from the original sensor IDs stored in the vehicle's ECU.

There are three ways available for Relearn: Static Learning, Self-Learning and Relearn by OBD.

Method 1 - Static Learning

Static learning requires the vehicle to be put into learning / retraining mode, and then follow the on-screen prompts to complete it.

Method 2 - Self-Learning

For some vehicles, the learning function can be completed by driving. Refer to the on-screen learning steps to do the operation.

Method 3 - Relearn by OBD

This function allows the diagnostic tool to write the sensor IDs to the TPMS module.

To perform relearn by OBD, firstly activate all sensors, and then use the diagnostic tool together with the included VCI to complete the learning steps following the on-screen instructions.

Troubleshooting

Below lists some frequently asked questions of the i-TPMS.

Q: Why does my i-TPMS always stay on welcome screen?

A: If the device keeps displaying the welcome screen, it indicates that it is not in TPMS function mode. If the diagnostic tool is performing the TPMS function, the device will switch to the corresponding function mode.

Q: Can I set the system language of my i-TPMS ?

A: It varies with the system language of the diagnostic tool/smartphone that connects it. Currently only English and simplified Chinese are available on the device.

If the device detects the system language of the diagnostic tool/smartphone is non-Chinese, it will change into English automatically no matter which language the diagnostic tool/smartphone is set as.

Q: My i-TPMS does not respond.

A: In this case, please carefully check the following:

- Whether the device is successfully connected to the diagnostic tool/smartphone wirelessly.
- Whether the device is powered on.
- Whether the device is damaged or defective.

Q: Why does my i-TPMS automatically power off?

A: Please check the following:

- Whether the device is fully discharged.
- If the device is not being charged and there is no operation on the device for 30 minutes, it will automatically power off to conserve battery power.

Troubleshooting

Q: My i-TPMS can not trigger sensor.

A: Please check the following:

- Whether the device is damaged or defective.
- Whether the sensor, module or ECU itself may be damaged or defective.
- The vehicle does not have a sensor even though a metal valve stem is present. Be aware of Schrader rubber style snap-in stems used on TPMS systems.
- You device may require a firmware upgrade.

Q: What to do if my i-TPMS encountered some unexpected bugs?

A: In this case, a firmware upgrade is required. On the TPMS version selection screen, tap **Firmware Update** to upgrade it.

FCC Statement

FCCID:XUJITPMS

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device is in compliance with the essential requirements and other relevant provisions of Radio Equipment Directive 2014/53/EU. The RF frequencies can be used in Europe without restriction.

컴플라이언스 정보

FCCID:XUJITPMS

당사에 의해 명시적으로 승인되지 않은 변경이나 수정을 진행할 경우 사용자의 기기 작동 권한을 무효화할 수 있습니다.

이 기기는 FCC 규정의 제 15조항을 준수합니다. 작동에는 다음 두 가지 조건이 적용됩니다:

(1) 이 장치는 간섭을 일으키지 않을 수 있습니다; 및

(2) 이 장치는 장치의 원치 않는 작동을 유발할 수 있는 간섭을 포함하여 모든 간섭을 수용해야 합니다.

참고: 이 기기는 테스트를 거쳐 B등급 디지털 장치에 대한 제한 사항을 준수하는 것으로 확인되었습니다.이 기기는 FCC 규정의 제 15조항을 준수합니다. 이러한 제한은 주거용 설치에서 유해한 간섭으로부터 합리적인 보호를 제공하도록 설계되었습니다. 이 기기는 무선 주파수 에너지를 생성, 사용 및 방출할 수 있으며 지침에 따라 설치 및 사용하지 않으면 무선 통신에 유해한 간섭을 일으킬 수 있습니다. 그러나 특정 설치에서 간섭이 발생하지 않는다는 보장은 없습니다. 이 기기가 라디오나 TV 수신에 유해한 간섭을 일으키는 경우(기기를 껐다 켜서 확인할 수 있음) 사용자는 다음 조치 중 하나 이상을 사용하여 간섭을 해결하는 것이 좋습니다.


-수신 안테나의 방향을 바꾸거나 재배치.

-기기와 수신기 사이의 간격 늘리기.

-수신기가 연결된 회로와 다른 회로의 콘센트에 기기 연결.

-대리점 또는 숙련된 라디오/TV 기술자에게 도움을 요청하세요.

이 장치는 무선 장비 지침 2014/53/EU의 필수 요구 사항 및 기타 관련 조항을 준수합니다. RF 주파수는 유럽에서 제한 없이 사용할 수 있습니다.



制作要求：

文件大小：78mmx210mm

装订方式：骑马钉

印刷方式：黑白印刷, 80g书写纸